



Installation Instructions

Important: Please read these instructions before starting work.

1. Check that there are no buried pipes or cables before drilling and holes. Take extreme care when using electrical equipment near water.
2. Do not fix accessories onto newly painted surfaces as chemical reactions could cause discoloration to the products. (Please refer to the manufactures instructions.)
3. We recommend the use of a specialized drill bit when fixing accessories to tiled areas.

Supplied Mounting hardware:

Mounting plate, screws and wall plugs

Mounting Instructions:

1. Establish the position for the accessories, making sure there is sufficient room.
2. Position the mounting plate onto the wall and mark attachment holes (making sure the mounting plate tab holes are on top), with a pencil. Ensure the marks are horizontal by use of a carpenter's level.
3. Drill holes to a minimum depth of 1" inch using a 3/16" inch drill bit. Gently insert the wall plugs into the hole either by hand, or by gently tapping with a rubber mallet, until they are flush with the wall. If need be, carefully increase the diameter of the hole to accommodate the anchor. The anchor must fit snugly into the wall to assure a secure fixation of the mounting plate.
4. Attach mounting plate with screws into wall plugs.
5. Secure basket mounting prongs onto mounting plate prong receiver.

Care Instructions:

We recommend regular cleaning with a mild soap and dried with a soft cloth. The use of abrasive cleaners or bleaches will damage the finish.

If further assistance is required, please contact Customer Service at 1-888-825-7266 (9am-5pm EST)